



Contact (866) 758-3900 for assistance.  
Do not return to place of purchase.

## Assembly Instructions

Model No. S-1178

### Hardware/Parts

Part	Description	Qty
1	Screen	1
2	Front Foot	2
A	Screw	4
B	Nut	4

### Steps

#### Step 1

Attach front feet to screen using 4 sets of screws (A) and nuts (B).

**CAUTION:** Keep this product clean by using a damp cloth. DO NOT use abrasive cleaners, as it will cause parts to tarnish.

### Tools Required for Assembly (Not Included)

Phillips Head Screw Driver and Adjustable Wrench.

